

Firestone

**World's Number 1
Air Spring.**



FIRESTONE INDUSTRIAL PRODUCTS COMPANY

NEW CANADIAN LOADSHARE[®]

Air Helper Springs

Kit Number

Model

MACK (2007 Applications)

CXP613 Pinnacle Day Cab	W29-358-0006 (plus WC9-358-0002 shock kit)
CHN613 Rawhide	W29-358-0017
CXN613 70" high rise	W29-358-0006
CT713 Granite	W29-358-0006

Kenworth (2007 Applications)

T600	W29-358-0006
W900	W29-358-0006
T300	W29-358-0001
T800	W29-358-0001

Volvo (2006 Applications)

VT64T800	W29-358-0006 (plus WC9-358-0002 shock kit)
VHD84B200	W29-358-0001
VNL64T670	W29-358-0006 (plus WC9-358-0002 shock kit)
WT64T880	W29-358-0006 (plus WC9-358-0002 shock kit)

Hino (2006 Applications)

308	W29-358-0016
338	W29-358-0016
258	W29-358-0016
185	W29-358-0016

Kit Number

Model

Peterbilt (2007 Applications)

388	W29-358-0006 (plus WC9-358-0002 shock kit)
386	W29-358-0001 (plus WC9-358-0002 shock kit)
387	W29-358-0004 (plus WC9-358-0002 shock kit)
367	W29-358-0006 (plus WC9-358-0002 shock kit)
335	W29-358-0001 (plus WC9-358-0002 shock kit)

Western Star

4900FA123	W29-358-0001
4900SA123	W29-358-0001 (plus WC9-358-0002 shock kit)
4900EX132	W29-358-0006 (plus WC9-358-0002 shock kit)

Sterling

ACTERRA 106	W29-358-0001 (plus WC9-358-0002 shock kit)
AT9500 113	W29-358-0001 (plus WC9-358-0002 shock kit)

International

(2006) 7600SFA 6x4	W29-358-0001
(2007) LH23SBA 6x4	No kit - Full air suspension
(2007) 9900i SFA 6x4	W29-358-0006 (plus WC9-358-0002 shock kit)
(2006) 4200 SBA 4x2 (RXT)	W29-358-0001

Freightliner

FLD 120SD Conventional	W29-358-0001 (plus WC9-358-0002 shock kit)
Columbia CL 120	W29-358-0001 (plus WC9-358-0002 shock kit)
M2-112 Conventional	W29-358-0001 (plus WC9-358-0002 shock kit)
Classic Conventional	W29-358-0006 (plus WC9-358-0002 shock kit)
CL-112 Conventional	W29-358-0001 (plus WC9-358-0002 shock kit)
Century S/T CST 120 Conventional	W29-358-0001 (plus WC9-358-0002 shock kit)
M2-106	W29-358-0001 (plus WC9-358-0002 shock kit)

